## Normal Mode Coordinates

In cartesian coordinates, expanding the potential operator around a point  $\mathbf{x}_0,$  the Hamiltonian can be written

$$\hat{H}(\mathbf{x}) = \sum_{i} -\frac{\hbar^{2}}{2m_{i}} \frac{\partial^{2}}{\partial x_{i}^{2}} + V_{0} + \sum_{i} \frac{\partial V}{\partial x_{i}} (x_{i} - x_{0i})$$
$$+ \sum_{i,j} \frac{1}{2} \frac{\partial^{2} V}{\partial x_{i} \partial x_{j}} (x_{i} - x_{0i}) (x_{j} - x_{0j}) + \dots$$
(1)

where  $V_0$  is  $V(\mathbf{x}_0)$  and the derivatives are evaluated at  $\mathbf{x}_0$ . If  $\mathbf{x}_0$  is at a minimum energy point, then

$$\frac{\partial V}{\partial x_i} = 0 \quad \forall i \quad . \tag{2}$$

Now use mass-scaled coordinates relative to  $\mathbf{x}_0$ 

$$x_i - x_{0i} \to \frac{1}{\sqrt{m_i}} \tilde{x}_i \implies \frac{\partial}{\partial x_i} \to \sqrt{m_i} \frac{\partial}{\partial \tilde{x}_i}$$
 (3)

so that the Hamiltonian is

$$\hat{H}(\tilde{\mathbf{x}}) = \sum_{i} -\frac{\hbar^2}{2} \frac{\partial^2}{\partial \tilde{x}_i^2} + V_0 + \sum_{i,j} \frac{1}{2} \mathcal{H}_{ij} \tilde{x}_i \tilde{x}_j + \dots$$
(4)

where  $\mathcal{H}_{ij}$  is the mass-weighted Hessian

$$\mathcal{H}_{ij} = \frac{1}{\sqrt{m_i}\sqrt{m_j}} \frac{\partial^2 V}{\partial x_i \partial x_j} \quad . \tag{5}$$

Normal coordinates,  ${\bf q}$  are defined by an orthonormal transformation

$$\tilde{x}_i = \sum_{\alpha} D_{\alpha i} q_{\alpha} \tag{6}$$

$$\mathbf{D}^T \mathbf{D} = \mathbf{1} \tag{7}$$

where the matrix  $\mathbf{D}$  contains the eigenvectors of the Hessian,

$$\mathbf{D}\mathcal{H}\mathbf{D}^T = \mathbf{w} \quad . \tag{8}$$

For reasons that will be clear below, the diagonal eigenvalue matrix  ${\bf w}$  can be written

$$w_{ij} = \omega_i^2 \delta_{ij} \quad . \tag{9}$$

As the eigenvectors are orthonormal,

$$\sum_{i} \frac{\partial^2}{\partial \tilde{x}_i^2} = \sum_{\alpha} \frac{\partial^2}{\partial q_{\alpha}^2} \tag{10}$$

and so

$$\hat{H}(\mathbf{q}) = V_0 + \sum_{\alpha} -\frac{\hbar^2}{2} \frac{\partial^2}{\partial q_{\alpha}^2} + \sum_{\alpha} \frac{1}{2} \omega_{\alpha}^2 q_{\alpha}^2 + \dots$$
(11)

Comparing this to the Hamiltonian for a harmonic oscillator,

$$\hat{H}(q) = -\frac{\hbar^2}{2m}\frac{\partial^2}{\partial q^2} + \frac{1}{2}m\omega^2 q^2 \quad , \tag{12}$$

the second and third terms have the form of a set of harmonic oscillators of unit mass.

A neater expression for the normal mode Hamiltonian, Eq. (11), can be made by a final transformation to dimensionless coordinates

$$q_{\alpha} \to \sqrt{\frac{\hbar}{\omega_{\alpha}}} Q_{\alpha} \implies \frac{\partial}{\partial q_{\alpha}} \to \sqrt{\frac{\omega_i}{\hbar}} \frac{\partial}{\partial Q_{\alpha}}$$
 (13)

$$\hat{H}(\mathbf{Q}) = V_0 + \frac{\hbar\omega_\alpha}{2} \left( \sum_{\alpha} -\frac{\partial^2}{\partial Q_{\alpha}^2} + Q_{\alpha}^2 \right) + \dots$$
(14)

## Notes

1. If atomic units are used in which  $\hbar = 1$  this can be written

$$\hat{H}(\mathbf{Q}) = V_0 + \frac{\omega_\alpha}{2} \left( \sum_\alpha -\frac{\partial^2}{\partial Q_\alpha^2} + Q_\alpha^2 \right) + \dots$$
(15)

and the frequency has units of energy.

2. In the GAUSSIAN program, the normal modes are obtained as a set of orthonormal vectors. These are the columns of **D**. To transform between cartesian and dimensionless coordinates,

$$\mathbf{Q} = \tilde{\mathbf{D}}(\mathbf{x} - \mathbf{x}_0) \tag{16}$$

$$\mathbf{x} = \mathbf{x}_0 + \tilde{\mathbf{D}}' \mathbf{Q} \tag{17}$$

where the transformation matrices are no longer orthonormal, but related to the Hessian eigenvectors by

$$\tilde{D}_{\alpha i} = D_{\alpha i} \sqrt{\frac{m_i \omega_\alpha}{\hbar}} \tag{18}$$

$$\tilde{D}'_{i\alpha} = D^T_{i\alpha}\sqrt{\frac{\hbar}{m_i\omega_\alpha}}$$
 (19)

Inserting constants, if  $\mathbf{x}$  is in Å,

$$\frac{\sqrt{m_i \hbar \omega_\alpha}}{\hbar} = 15.4644 \sqrt{\frac{m_i}{[\text{amu}]} \frac{\hbar \omega_\alpha}{[\text{eV}]}} = 0.172 \sqrt{\frac{m_i}{[\text{amu}]} \frac{\hbar \omega_\alpha}{[\text{cm}^{-1}]}}$$
(20)